

HiTemp140-TS

Thermal Shield for the HiTemp140 Data Logger Series

The HiTemp140-TS is a thermal shield designed for use with the HiTemp140 data logger. This durable enclosure allows the data logger to be used in temperatures from -200 °C to +250 °C, making it ideal for peanut roasting, food processing, autoclave validation and other extreme temperature applications.

To use, simply place the HiTemp140 in the IFC400 or IFC406 docking station (sold separately). Use the MadgeTech software to program a start method and reading interval. Place the HiTemp140 in the HiTemp140-TS enclosure and the device is ready to be deployed.

The HiTemp140-TS flush style is designed to have the probe entirely exposed while the data logger is protected by the thermal shield. This allows full use of the length of the probe for applications that require internal temperature monitoring. The Vented style offers more probe protection and is designed for applications where the data logger might be subject to movement in a fully submerged application.



Features

- Withstands Temperatures between -200 °C up to +250 °C (see specifications chart)
- Small Diameter: 2.0 in (51 mm)
- Submersible

Applications

- Peanut Roasting
- Food Processing
- Autoclave Validation
- Conveyor Ovens
- Dishwasher Testing

SPECIFICATIONS

Specifications are subject to change without notice. Specific warranty remedy limitations apply. Call (603) 456-2011 or go to madgetech.com for details.

Ambient Temperature	HiTemp140-TS (Flush)		HiTemp140-TS (Vented)	
	Exposure Time in Air	Exposure Time in Liquid	Exposure Time in Air	Exposure Time in Liquid
-200 °C (-328 °F)	12 minutes	N/A	14 minutes	N/A
-180 °C (-292 °F)	13 minutes	N/A	15 minutes	N/A
-160 °C (-256 °F)	15 minutes	N/A	16 minutes	N/A
-140 °C (-220 °F)	17 minutes	N/A	18 minutes	N/A
-120 °C (-184 °F)	19 minutes	N/A	21 minutes	N/A
-100 °C (-148 °F)	22 minutes	N/A	24 minutes	N/A
-80 °C (-112 °F)	27 minutes	N/A	30 minutes	N/A
-60 °C (-76 °F)	37 minutes	22 minutes	42 minutes	25 minutes
-40 °C to +140 °C (-40 °F to +284 °F)	Indefinitely	Indefinitely	Indefinitely	Indefinitely
+150 °C (+302 °F)	59 minutes	34 minutes	66 minutes	40 minutes
+160 °C (+320 °F)	51 minutes	29 minutes	57 minutes	34 minutes
+170 °C (+338 °F)	43 minutes	25 minutes	48 minutes	29 minutes
+180 °C (+356 °F)	37 minutes	23 minutes	42 minutes	26 minutes
+190 °C (+374 °F)	34 minutes	20 minutes	38 minutes	23 minutes
+200 °C (+392 °F)	31 minutes	18 minutes	34 minutes	21 minutes
+210 °C (+410 °F)	29 minutes	17 minutes	32 minutes	19 minutes
+220 °C (+428 °F)	27 minutes	16 minutes	30 minutes	18 minutes
+230 °C (+446 °F)	25 minutes	15 minutes	27 minutes	17 minutes
+240 °C (+464 °F)	23 minutes	14 minutes	26 minutes	16 minutes
+250 °C (+482 °F)	22 minutes	13 minutes	24 minutes	15 minutes

Operating Environment	-200 °C to +250 °C (-328 °F to +482 °F) (Time limited) 0 %RH to 100 %RH, 0.002 PSIA to 100 PSIA
Dimensions	Flush Top: 2.75 in x 2.0 in dia.(69.85 mm x 51 mm dia.) Vented Top: 4.3 in x 2.0 in dia.(109.2 mm x 50.8 mm dia.)
Material	Enclosure: PTFE
Weight	Flush: 6.7 oz (190 g) - not including data logger Vented: 9.5 oz (270 g) - not including data logger

Disclaimer & Terms of Use

Published specifications can be used to determine maximum allowable exposure times for the HiTemp140 with Thermal Shield at different temperatures beyond the normal operating range of the logger. Both the data logger and Thermal Shield must be at ambient temperature (approximately 25 °C) before being placed in the extreme temperature environment.

Immediately following exposure to high temperature, the data logger should be removed from the thermal shield (using appropriate precautions, as it could be VERY hot) OR the data logger and shield should be placed in a water bath (approximately 25 °C) for at least 15 minutes to allow it to cool. Failing to do this may allow heat trapped in the Thermal Shield to continue to heat the data logger to potentially unsafe levels.

If your application involves a ramp up to a temperature above 140 °C and/or any complex temperature profile that isn't simply a constant temperature, please contact MadgeTech to determine whether the HiTemp140 with Thermal Shield is suitable.

Please provide MadgeTech with a detailed description of your temperature profile, including temperatures, durations, ramp times, and process media (air, steam, oil, water, etc.) If MadgeTech is unable to definitively calculate the suitability of our product for your application, we can provide a test unit outfitted with a high temperature indicator sticker. This sticker has an indicator dot which will turn black if exposed to temperatures above 143 °C. Apply the sticker to the bottom of the data logger itself (not the thermal shield), remove the battery for safety, place the data logger into the thermal shield and run the assembly through the proposed temperature program. The first indicator dot on the sticker will turn black at 143 °C. If that happens, the HiTemp140 with thermal shield is not appropriate for the application and we will work to find a solution that is.

Ordering Information

HITEMP140-TS (Vented)	PN 900262-00	Thermal Shield (vented) for the HiTemp140-5.25/7, HiTemp140-PT and HiTemp140-FP Data Logger
HITEMP140-TS (Flush)	PN 900263-00	Thermal Shield (flush) for the HiTemp140-5.25/7, HiTemp140-PT and HiTemp140-FP Data Logger

For Quantity Discounts call (603) 456-2011 or email sales@madgetech.com

